
DC and AC Coupon Technology

Michael Placzek

ARK Engineering & Technical Services, Inc



DC & AC Coupon Technology

- What are they?
- What do they look like?
- How do you install them?
- What is the Data From A Coupon Good For?
- How Do You Read Them?




DC & AC Coupon Technology

- This is a coupon:



Coupon History

- Traditionally Coupons Were for Internal Corrosion and Atmospheric Corrosion Monitoring and Testing



Coupon History

- Internal Corrosion Coupons Were Placed Inside the Pipeline To Monitor the Corrosive Effects of What the Pipeline Carried.
- Liquids or Gas




FIG. 1
Coupons shown relative to pipe normal position.



Coupon History

- Atmospheric Coupons Either Tested Multiple Metals or Multiple Coatings to a Corrosive Atmosphere



Coupon Definition

- A coupon is a representative piece of material or metal subjected to an environment for testing purposes.
- SP0104-2014: *“Cathodic Protection Coupon – a coupon that is connected to the external surface of, and immersed in the electrolyte adjacent to, the structure being protected by cathodic protection.”*



Pipeline Coupon Examples

- Basic
 - Simple Single Coupon
 - Two Wire




Pipeline Coupon Examples

- More Advanced
 - Multiple Coupons
 - 1 cm² for AC
 - 2- 100 cm² for DC
 - Reference Electrodes
 - Test Station Switching



Coupon 101 – Install

- Coupon is placed in the ground next to the pipe – **IN THE SAME ELECTROLYTE**
- Cpn is connected to pipeline in test station
- Ref Cell is used to read pipe or cpn potentials



Coupon 101 – How to Read

- Regular Ref Cell Placement
- Coupon Still Hooked Up to Pipe – Read Both
- Break Coupon Lead Wire – Read Just Coupon
- Sounds Simple – Right?
- Well It Is – Sort Of



Coupon 201

- Buried Reference Electrodes Fail!
- Coupons can upset CP-Pipeline circuit.
 - Well coated pipeline – coupon is large holiday
 - Too many coupons on a well coated pipeline
 - Coupon can become part of interference circuit
- Wires Break
- Forget to Flip the Switch (On or Off)
- Lightning Damage to Coupon or Circuit Card



Data from a Coupon - DC

- Native Potentials – This Coupon is never hooked to pipeline
- ON Potentials – Read with the Pipeline
- I-Off Potentials – Disconnect Coupon and read the Coupon Instant Off
 - Do not Have to Interrupt Multiple Rectifiers
 - Direct Connect Sacrificial Anodes
 - Interference Studies
 - Multiple Pipelines in single ROW



Data from Coupon – DC & AC

- Measure Current Coming From Coupon
- Calculate Current Density
- Common Unit of Measure is A/m^2
 - Amperes Per Square Meter
 - **Watch Your Units!!!!!!**
 - Real current measurements can be mA or μA
 - Clamp-On Ammeters Cannot Read This.
 - Coupons are measured in cm^2 .
 - For a 1 cm^2 AC coupon: $100A/m^2 = 10mA/cm^2$
 - For a 100 cm^2 DC coupon: $100\text{ A}/m^2 = 1A/cm^2$



Why Is Current Density Important?

- “*Cathodic Protection*” by PE Francis
 - Expected DC Current Densities for CP in:
 - Acidic Solutions: 350 - 500 A/m²
 - Saline Solutions: 0.3 – 10 A/m²
 - Sea Water: 0.05 – 0.15 A/m²
 - Saline Mud: 0.025 – 0.05 A/m²
- “*AC Corrosion-A New Challenge To Pipeline Integrity*” by Gummow/Wakelin/Segall
 - Expected AC Corrosion Damage for Given AC Current Densities on Adequately Cathodically Protected Pipelines
 - $d < 20 \text{ A/m}^2$: No AC Induced Corrosion Expected
 - $20 \text{ A/m}^2 < d < 100 \text{ A/m}^2$: Unpredictable
 - 100 A/m^2 : Expected



Why Current Density is Important?

- “*AC Corrosion – Case Histories, Test Procedures & Mitigation*” by Gummow/Wakelin/Segall
- AC Corrosion Rates
 - Are highest at holidays having a surface area of 1 – 3 cm²
 - Increase in chloride containing or deaerated environments
 - Increase with decreasing AC frequency below 100 Hz
 - Decrease with increasing CP current density
 - Decrease with time
- $i_{ac} = \frac{8V_{ac}}{\rho\pi d}$
 - i_{ac} = AC current density
 - V_{ac} = AC voltage of pipeline to remote earth
 - ρ = soil resistivity
 - d = diameter of a circular holiday having an area equal to that of the actual holiday



How do you read them?

- Directly – Voltmeter for Potential Measurements
- Directly – Ammeter for Coupon Current Measurements
 - Very Low Scale Such as Milliamps or even Microamps
 - Careful – Breaking the circuit to hook up the ammeter in series causes depolarization
- Remote Monitoring – Reads It For You
 - Remote Access
 - Constant Monitoring
 - Records History
- CAUTION: Every Meter Has Errors.
 - Since you are reading very small numbers, a small error can sway data.



Guidance

- Company SOPs
- NACE SP0169-Latest Edition for Magnitudes – *“Control of External Corrosion on Underground or Submerged Metallic Piping Systems”*
- NACE SP0104-Latest Edition for How To – *“The Use of Coupons for Cathodic Protection Monitoring Applications”*
- Vendors and Suppliers – Materials and Individual Equipment Instruction

